Dell Inspiron 5100 PP07L Hard Drive Replacement

If you want to replace your hard drive for a larger drive or if it's corrupted.

Written By: May Chauvin

INTRODUCTION

You will learn how to remove the hard drive.

TOOLS:

- Phillips #1 Screwdriver (1)

Step 1 — Hard Drive

- With the lid closed, place the laptop upside-down on a flat surface.

Step 2

- Remove the two 5.8mm screws securing the hard drive bay.
  - If the computer was right-side-up and rotated for use, the bay would be found in the rear left corner.

Step 3



- Grasp the plastic bay handle and slide outwards to remove.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2015-05-01 02:47:21 PM.